

Dimension

L * W * H 325.8 * 107 * 41 (1U) mm 12.82 * 4.21 * 1.61(1U) inch































■ Features

- · Universal AC input / Full range
- Power supply or charger mode selectable by PMBus, CANBus or SBP-001(only for 24V/48V models)
- Built-in 2/3 stage charging curves and programmable curve (only for 24V/48V models)
- · High efficiency up to 94.5%
- Built-in programmable output voltage and output current
- Built-in OR-ing FET or Diode, support hot swap (hot plug)
- Active current sharing up to 10 rack shelves and the maximum power supply that can be connected in parallel is 40 units
- Support PMBus/CANBus protocol
- Built-in intelligent fan speed control
- Protections: Short circuit / Overload / Over voltage / Over temperature
- · Design refer to SEMI F47 standard specification
- 5 years warranty

Applications

- Industrial automation
- · Distributed power architecture system
- Wireless/telecommunication solution
- · Redundant power system
- Large scale DC UPS or emergency backup system
- Electric scooter or vehicle charger station
- Wastewater treatment system
- · Electrolysis system


■ GTIN CODE

MW Search: https://www.meanwell.com/serviceGTIN.aspx

Description

NCP-3200 is a 3.2KW dual-purpose(Switching Power Supply & Charger) rack-mounted AC/DC power supply with 1U low profile design and high power density up to 37W/inch³. This series operates at 90~264VAC input voltage and offers the models with the DC output mostly demanded by the industry. Each model is cooled by the built-in DC fan with fan speed control and working for the temperature up to 70°C. NCP-3200 provides vast design flexibility by equipping with PMBus and CANbus, two international communication protocols which can be selected for industrial control and power supply control, and can also be used directly with intelligent controller CMU2. Active current sharing up to 10 rack shelves (DHP-1UT-B) and the maximum power supply that can be connected in parallel is 40 units, remote ON/OFF control, auxiliary power, alarm signal, and others.

■ Model Encoding / Order Information



% Note 1: 19" rack shelf, DHP-1UT-B(HV), available. Details available on http://www.meanwell.com/

X Note 2: Control/Monitor unit, CMU2, available. Details available on http://www.meanwell.com/

Туре	Communication Protocol	Note
Blank	PMBus protocol	In Stock
CAN	CANBus protocol	In Stock



SPECIFICATION FOR POWER SUPPLY MODE (Default)

MODEL		NCP-3200-24		NCP-3200-48		
	DC VOLTAGE (factory default)	24V		48V		
	RATED CURRENT (factory default)	133A		67A		
	CURRENT RANGE	0 ~ 133A		0 ~ 67A		
	RATED POWER (max.)	3192W		3216W		
	RIPPLE & NOISE (max.) Note.2,3	300mVp-p		480mVp-p		
OUTPUT	VOLTAGE ADJ. RANGE	23.5 ~ 30V		47.5 ~ 58.8V		
	VOLTAGE TOLERANCE Note.4			±1.0%		
	LINE REGULATION	±0.5%		±0.5%		
	LOAD REGULATION	±0.5%		±0.5%		
	SETUP, RISE TIME	1500ms, 60ms/230VAC at full load		_ 5.5 /5		
	HOLD UP TIME (Typ.)	,	230VAC at full load			
		90 ~ 264VAC				
	FREQUENCY RANGE	47 ~ 63Hz				
	POWER FACTOR (Typ.)	9.97/230VAC at full load				
INPUT		93.5%		94.5%		
141 01	() ()	17A/230VAC		34.370		
	INRUSH CURRENT (Typ.)	COLD START 55A/230VAC				
	LEAKAGE CURRENT	<2mA / 230VAC				
	LLANAGE CURRENT					
	OVERLOAD	105 ~ 115% rated current	an abut dayin O/D It	offer Feed Affer CID	valtaga falla ya navya t	
		Protection type : Constant current limitin	<u> </u>	63 ~ 75V	voltage rails, re-power on to recover	
PROTECTION	OVER VOLTAGE	31.5 ~ 37.5V		63 ~ 75V		
		Protection type : Shut down o/p voltage,	<u> </u>			
	OVER TEMPERATURE	Shut down o/p voltage, recovers automa	, , ,			
	OUTPUT VOLTAGE PROGRAMMABLE(PV)	Adjustment of output voltage is allowa		ial output voltage		
	CONSTANT CURRENT LEVEL	Please refer to the Function Manual in		of rated ourrant		
	PROGRAMMABLE(PC)	Adjustment of constant current level is allowable to 20 ~ 100% of rated current Please refer to the Function Manual in following pages				
FUNCTION	REMOTE ON-OFF CONTROL	By electrical signal or dry contact Power ON:short Power OFF:open. Please refer to the Function Manual in following pages				
FUNCTION		Compensate voltage drop on the load w				
	REMOTE SENSE	Please refer to the Function Manual in f				
	CURRENT SHARING	Active current sharing up to 10 rack shelves(DHP-1UT-B) and the maximum supply units that can be connected in parallel is 40				
	AUXILIARY POWER	5V @ 0.3A, tolerance \pm 10%, ripple	150mVp-p, 12V @ 0.8A,	tolerance ±10%, rip	pple 450mVp-p	
	ALARM SIGNAL	Isolated TTL signal output for T-Alarm, AC-OK and DC-OK. Please refer to the Function Manual in following pages				
	WORKING TEMP.	-30 ~ +70°C (Refer to "Derating Curve")				
	WORKING HUMIDITY	20 ~ 90% RH non-condensing				
ENVIRONMENT	STORAGE TEMP., HUMIDITY	$-40 \sim +85^{\circ}$ C, $10 \sim 95\%$ RH non-condensing				
	TEMP. COEFFICIENT	±0.03%/°C (0~50°C)				
	VIBRATION	10 ~ 500Hz, 2G 10min./1cycle, 60min. each along X, Y, Z axes				
	SAFETY STANDARDS	UL62368-1, CSA C22.2 No. 62368-1, TUV BS EN/EN62368-1, EAC TP TC 004 approved; Design refer to AS/NZS62368.1				
	WITHSTAND VOLTAGE	I/P-O/P:3KVAC I/P-FG:2KVAC O/P	-FG:1.5KVAC		· •	
	ISOLATION RESISTANCE	I/P-O/P, I/P-FG, O/P-FG:100M Ohms / 5				
		Parameter	Standard		Test Level / Note	
		Conducted	BS EN/EN55032 (CISI	PR32)	Class B	
	EMC EMISSION	Radiated	BS EN/EN55032 (CISI		Class A	
	Line Linesion	Harmonic Current	BS EN/EN61000-3-2	1102)	Class A	
		Voltage Flicker	BS EN/EN61000-3-3			
SAFETY &		BS EN/EN55024, BS EN/EN61000-6-2;		at 200\/AC		
EMC (Note 10)		Parameter	Standard	at 200 V/10	Test Level / Note	
11010 10)		ESD	BS EN/EN61000-4-2		Level 3, 8KV air ; Level 2, 4KV contact	
		Radiated	BS EN/EN61000-4-3		Level 3	
		EFT / Burst	BS EN/EN61000-4-4		Level 3	
	EMC IMMUNITY				2KV/Line-Line 4KV/Line-Earth	
		Surge Conducted	BS EN/EN61000-4-5 BS EN/EN61000-4-6		Level 3	
		Magnetic Field			Level 4	
		Voltage Dips and Interruptions	BS EN/EN61000-4-8 BS EN/EN61000-4-11		>95% dip 0.5 periods, 30% dip 25 period >95% interruptions 250 periods	
	MTBF	510.5K hrs min. Telcordia SR-332 (B	ellcore) ; 45.8K hrs min.	MIL-HDBK-217F (25		
OTHERS	DIMENSION	325.8*107*41mm (L*W*H)	0110010j , 40.0K III3 IIIII.	WIL TIDDI(-2171 (20	, -,	
		2.3Kg;4pcs/10.2Kg/1.09CUFT				
PACKING 1. All parameters NOT spe		=.o.tg, 1poo/ 10.21tg/ 1.00001 1				

NOTE

- 2. Ripple & noise are measured at 20MHz of bandwidth by using a 12" wisted pair-wire terminated with a 0.1uf & 47uf parallel capacitor.

 3. Under variable load application or parallel operation ripple of the output voltage may be higher than the SPEC at light load condition. It will go back to normal
- ripple level once the output load is more than 5%.
- Tolerance : includes set up tolerance, line regulation and load regulation.
 RCM is on a voluntary basis and meets relevant IEC or AS/NZS standards complying with AS/NES 4417.1.
- Derating may be needed under low input voltages. Please check the derating curve for more details.
 The efficiency is measured at 75% load.
- 8. If use PV signal to adjust Vo, under certain operating conditions, ripple noise of Vo might slightly go over rating defined in this specification.
- 9. Output will shut down after O/P voltage is below < 80% of Vset for 5 sec, re-power on to recover.

 10. The power supply is considered a component which will be installed into a final equipment. All the EMC tests are been executed by mounting the unit on
- a 600mm*900mm metal plate with 1mm of thickness. The final equipment must be re-confirmed that it still meets EMC directives. For guidance on how to perform these EMC tests, please refer to "EMI testing of component power supplies." (as available on https://www.meanwell.com//Upload/PDF/EMI_statement_en.pdf)
- 11. The ambient temperature derating of 3.5°C/1000m with fanless models and of 5°C/1000m with fan models for operating altitude higher than 2000m(6500ft).
- ** Product Liability Disclaimer: For detailed information, please refer to https://www.meanwell.com/serviceDisclaimer.aspx



SPECIFICATION FOR POWER SUPPLY MODE (Default)

	NCP-3200-380					
DC VOLTAGE (factory default)	380V					
, , ,	8.4A					
	0 ~ 9.6A					
. , ,	F 334 ~ 400V					
. ,						
		/ 220VAC at full load				
		/ 230 VAC at full load				
LEAKAGE CURRENT	1 11 1					
OVERLOAD	105 ~ 115% rated current					
	**	ting, shut down O/P voltage after 5 sec. Af	ter O/P voltage falls, re-power on to recover			
OVER VOLTAGE	127 1771					
OVER VOLINGE	Protection type : Shut down o/p voltag	e, re-power on to recover				
OVER TEMPERATURE	Shut down o/p voltage, recovers autor	natically after temperature goes down				
OUTPUT VOLTAGE		·	tage			
. ,	0.0					
			se refer to the Function Manual in following pages			
		Active current sharing up to 10 rack shelves(DHP-1UT-BHV) and the maximum supply units that can be connected in parallel is 40				
		1111				
		·	unction Manual III following pages			
	, ,	?)				
	· · · · · · · · · · · · · · · · · · ·	nsing				
	•					
		<u> </u>	approved; Design refer to AS/NZS62368.1			
ISOLATION RESISTANCE	,					
			Test Level / Note			
			Class B			
EMC EMISSION		,	Class A			
			Class A			
	, , , , , , , , , , , , , , , , , , ,	, ,				
			Test Level / Note			
			Level 3, 8KV air ; Level 2, 4KV contact			
	Radiated	BS EN/EN61000-4-3	Level 3			
EMC IMMUNITY	EFT / Burst	BS EN/EN61000-4-4	Level 3			
	Surge	BS EN/EN61000-4-5	2KV/Line-Line 4KV/Line-Earth			
	Conducted	BS EN/EN61000-4-6	Level 3			
	Magnetic Field	BS EN/EN61000-4-8	Level 4			
		DO EN/ENCADOD 4 44	>95% dip 0.5 periods, 30% dip 25 period			
	Voltage Dips and Interruptions	BS EN/EN61000-4-11	>95% interruptions 250 periods			
MTBF		(Bellcore); 45.8K hrs min. MIL-HDBK-2	2			
MTBF DIMENSION			2			
	CURRENT (factory default) CURRENT RANGE RATED POWER (max.) FULL POWER VOLTAGE RANGE RIPPLE & NOISE (max.) Note.2,3 VOLTAGE ADJ. RANGE VOLTAGE TOLERANCE Note.4 LINE REGULATION LOAD REGULATION SETUP, RISE TIME HOLD UP TIME (Typ.) VOLTAGE RANGE NOTE.6 FREQUENCY RANGE POWER FACTOR (Typ.) NOTE.7 AC CURRENT (Typ.) NOTE.6 INRUSH CURRENT (Typ.) LEAKAGE CURRENT OVERLOAD OVER VOLTAGE OUTPUT VOLTAGE PROGRAMMABLE(PV) CONSTANT CURRENT LEVEL PROGRAMMABLE(PC) REMOTE ON-OFF CONTROL CURRENT SHARING AUXILIARY POWER ALARM SIGNAL WORKING HUMIDITY STORAGE TEMP., HUMIDITY TEMP. COEFFICIENT VIBRATION SAFETY STANDARDS WITHSTAND VOLTAGE EMC EMISSION	DC VOLTAGE (factory default) 8.4A CURRENT (factory default) 8.4A CURRENT RANGE 0 ~ 9.6A 3206.4W FULL POWER VOLTAGE RANGE 3206.4W FULL POWER VOLTAGE RANGE 260 ~ 400V VOLTAGE ADJ. RANGE 260 ~ 400V VOLTAGE ADJ. RANGE 260 ~ 400V VOLTAGE TOLERANCE Note. 2,3 4000mVp-p VOLTAGE TOLERANCE Note. 4 ± 1.0% LINE REGULATION ± 0.5% SETUP, RISE TIME 1500ms, 60ms/230VAC at full load 8ms 230VAC at 70% load 8ms VOLTAGE RANGE Note. 6 90 ~ 264VAC 127 ~ 400VDC FREQUENCY RANGE 47 ~ 63Hz POWER FACTOR (Typ.) Note. 6 77A/230VAC at full load 8ms VOLTAGE RANGE Note. 6 77A/230VAC at full load 8ms VOLTAGE RANGE Note. 6 77A/230VAC 127 ~ 400VDC VOLTAGE Note. 6 77A/230VAC 127 ~ 400VDC VOLTAGE Note. 6 17A/230VAC VOLTAGE 105 ~ 115% rated current Imid VOLTAGE POWER TACTOR (Typ.) VOLTAGE Protection type : Constant current limid VOLTAGE Protection type : Shut down o/p voltage Note. 6 VOLTAGE Protection type : Shut down o/p voltage Note. 7 N	DC VOLTAGE (factory default) 8.4			

NOTE

- 2. Ripple & noise are measured at 20MHz of bandwidth by using a 12" twisted pair-wire terminated with a 0.1uf & 47uf parallel capacitor.

 3. Under variable load application or parallel operation ripple of the output voltage may be higher than the SPEC at light load condition. It will go back to normal
- ripple level once the output load is more than 5%.
- Tolerance : includes set up tolerance, line regulation and load regulation.
 RCM is on a voluntary basis and meets relevant IEC or AS/NZS standards complying with AS/NES 4417.1.
- 6. Derating may be needed under low input voltages. Please check the derating curve for more details.
- 7. The efficiency is measured at 75% load.
 8. If use PV signal to adjust Vo, under certain operating conditions, ripple noise of Vo might slightly go over rating defined in this specification.
- 9. Output will shut down after O/P voltage is below < 80% of Vset for 5 sec, re-power on to recover.

 10. The power supply is considered a component which will be installed into a final equipment. All the EMC tests are been executed by mounting the unit on a 600mm*900mm metal plate with 1mm of thickness. The final equipment must be re-confirmed that it still meets EMC directives. For guidance on how to perform these EMC tests, please refer to "EMI testing of component power supplies."

 (as available on https://www.meanwell.com//Upload/PDF/EMI_statement_en.pdf)

 11. The ambient temperature derating of 3.5°C/1000m with fanless models and of 5°C/1000m with fan models for operating altitude higher than 2000m(6500ft).
- Product Liability Disclaimer: For detailed information, please refer to https://www.meanwell.com/serviceDisclaimer.aspx

SPECIFICATION FOR CHARGER MODE (Selectable by PMBus, CANBus or SBP-001)


3200W 2-in-1 Rack-mounted Switching Power Supply & Battery Charger

MODEL		NCP-3200-24		NCP-3200-48	
	BOOST CHARGE VOLTAGE(Vboost)(default)	28.8V		57.6V	
	FLOAT CHARGE VOLTAGE(Vfloat)(default)	27.6V		55.2V	
	CONSTANT CURRENT(CC)(default)	110A		55A	
OUTPUT	RECOMMENDED BATTERY	330 ~ 1000Ah		180 ~ 550Ah	
	CAPACITY(AMP HOURS) Note.3	1350 ~ 1000AII		160 ~ 550AII	
	LEAKAGE CURRENT FROM BATTERY(Typ.)	<1.5mA			
	VOLTAGE RANGE Note.4	90 ~ 264VAC 127 ~ 400VDC			
	FREQUENCY RANGE	47 ~ 63Hz			
	POWER FACTOR (Typ.)	0.97/230VAC at full load).97/230VAC at full load		
INPUT	EFFICIENCY (Typ.)	93% 94%			
	AC CURRENT (Typ.) Note.4	17A/230VAC			
	INRUSH CURRENT (Typ.)	COLD START 55A/230VAC			
	LEAKAGE CURRENT	<2mA / 230VAC			
		31.5 ~ 37.5V		63 ~ 75V	
PROTECTION	OVER VOLTAGE	Protection type : Shut down o/p voltage, r	e-power on to recover		
TROTEGION	OVER TEMPERATURE	Shut down o/p voltage, recovers automati	•	noes down	
	REMOTE ON-OFF CONTROL	By electrical signal or dry contact Power		-	the Function Manual in following pages
	CURRENT SHARING	Active current sharing up to 10 rack shelv			
FUNCTION	AUXILIARY POWER	5V @ 0.3A, tolerance \pm 10%, ripple 15		- 117	<u>'</u>
	ALARM SIGNAL	Isolated TTL signal output for T-Alarm, AC			
		-30 ~ +70°C (Refer to "Derating Curve")	-OK allu DO-OK. Fleas	e refer to the Function	Maridal III Tollowing pages
	WORKING TEMP.	\			
	WORKING HUMIDITY	20 ~ 90% RH non-condensing			
ENVIRONMENT	STORAGE TEMP., HUMIDITY	-40 ~ +85°C, 10 ~ 95% RH non-condensing			
	TEMP. COEFFICIENT	±0.03%/°C (0~50°C)			
	VIBRATION	10 ~ 500Hz, 2G 10min./1cycle, 60min. each along X, Y, Z axes			
	SAFETY STANDARDS	UL62368-1, CSA C22.2 No. 62368-1, TU\		AC TP TC 004 approve	d ; Design refer to AS/NZS62368.1
	WITHSTAND VOLTAGE	I/P-O/P:3KVAC I/P-FG:2KVAC O/P-F			
	ISOLATION RESISTANCE	I/P-O/P, I/P-FG, O/P-FG:100M Ohms / 50			
		Parameter	Standard		Test Level / Note
		Conducted	BS EN/EN55032 (CIS	,	Class B
	EMC EMISSION	Radiated	BS EN/EN55032 (CIS	,	Class A
		Harmonic Current	BS EN/EN61000-3-2		Class A
SAFETY &		Voltage Flicker	BS EN/EN61000-3-3		
EMC		BS EN/EN55024, BS EN/EN61000-6-2			
(Note 6)		Parameter	Standard		Test Level / Note
		ESD	BS EN/EN61000-4-2		Level 3, 8KV air ; Level 2, 4KV contact
		Radiated	BS EN/EN61000-4-3		Level 3
	EMC IMMUNITY	EFT / Burst	BS EN/EN61000-4-4		Level 3
		Surge	BS EN/EN61000-4-5		2KV/Line-Line 4KV/Line-Earth
		Conducted	BS EN/EN61000-4-6		Level 3
		Magnetic Field	BS EN/EN61000-4-8		Level 4
		Voltage Dips and Interruptions	BS EN/EN61000-4-1	1	>95% dip 0.5 periods, 30% dip 25 periods, >95% interruptions 250 periods
	MTBF	510.5K hrs min. Telcordia SR-332 (Bellcore) ; 45.8K hrs min. MIL-HDBK-217F (25°C)			°C)
OTHERS	OTHERS DIMENSION 325.8*107*41mm (L*W*H)				
	PACKING	2.3Kg;4pcs/10.2Kg/1.09CUFT			
NOTE	All parameters NOT special This is MEAN WELL's sugg Derating may be needed ur RCM is on a voluntary basis The charger is considered a a 600mm*900mm metal pla perform these EMC tests, p (as available on https://www The ambient temperature default.	or charger specification may be required for different battery specification. Please contact battery vendor and MEAN WELL for details. S NOT specially mentioned are measured at 230VAC input, rated load and 25°C of ambient temperature. WELL's suggested range. Please consult your battery manufacturer for their suggestions about maximum charging current limitation. be needed under low input voltages. Please check the derating curve for more details. voluntary basis and meets relevant IEC or AS/NZS standards complying with AS/NES 4417.1. s considered a component which will be installed into a final equipment. All the EMC tests are been executed by mounting the unit on mm metal plate with 1mm of thickness. The final equipment must be re-confirmed that it still meets EMC directives. For guidance on how to EMC tests, please refer to "EMI testing of component power supplies." on https://www.meanwell.com/Upload/PDF/EMI_statement_en.pdf) emperature derating of 3.5°C/1000m with fanless models and of 5°C/1000m with fan models for operating altitude higher than 2000m(6500fit) ity Disclaimer: For detailed information, please refer to https://www.meanwell.com/serviceDisclaimer.aspx			





PFC fosc: 110KHz PWM fosc: 90KHz




■ STATIC CHARACTERISTICS

(%) 90 100 115 180 264 INPUT VOLTAGE (VAC) 60Hz


■ DERATING LOADs vs INPUT VOLTAGE

INPUT MODEL	24V	48V	380V
180~264VAC	3192W	3216W	3192W
	133A	67A	8.4A
90VAC	1596W	1608W	1596W
BUVAC	66.5A	33.5A	4.2A

■ DERATING CURVE



■ EFFICIENCY vs LOAD (48V MODEL)



The curve above is measured at 230VAC.




■ FUNCTION MANUAL

1. Charging Curve (Charger mode only available for 24V/48V models)

- ₩ By default, the unit operates in power supply mode, and it can be configured to charger mode by PMBus, CANBus or SBP-001.
- * By factory default, this charger performs the default curve which can be programmed via PMBus and CANBus. Charging functions, including charging timeouts for each stage, can be enabled through the communication interfaces.
- ** To accommodate the parameters of the charging curve, SBP-001, the smart battery charging programmer designed by MEAN WELL, and a personal computer are needed. Please contact MEAN WELL for details.

※ 2 stage charging curve




State	NCP-3200-24	NCP-3200-48
Constant Current	110A	55A
Vboost	28.8V	57.6V

© Suitable for lead-acid batteries (flooded, Gel and AGM) and Li-ion batteries (lithium iron and lithium manganese).

© Embedded 2 stage charging curves

MODEL	Description	CC(default)	Vboost
	Default, programmable		28.8
24V	Pre-defined, gel battery	110A	28
247	Pre-defined, flooded battery	TIUA	28.4
	Pre-defined, AGM battery		29
	Default, programmable		57.6
48V	Pre-defined, gel battery	55A	56
400	Pre-defined, flooded battery	33A	56.8
	Pre-defined, AGM battery		58

imes 3 stage charging curve (default)



State	NCP-3200-24	NCP-3200-48
Constant Current	110A	55A
Vboost	28.8V	57.6V
Vfloat	27.6V	55.2V

© Suitable for lead-acid batteries (flooded, Gel and AGM) and Li-ion batteries (lithium iron and lithium manganese).

\bigcirc Embedded 3 stage charging curves

MODEL	Description	CC(default)	Vboost	Vfloat
	Default, programmable		28.8	27.6
24V	Pre-defined, gel battery	110A	28	27.2
241	Pre-defined, flooded battery	IIIUA	28.4	26.8
	Pre-defined, AGM battery		29	27
	Default, programmable	55A	57.6	55.2
48V	Pre-defined, gel battery		56	54.4
400	Pre-defined, flooded battery) 55A	56.8	53.6
	Pre-defined, AGM battery		58	54

2. Front Panel LED Indicators

X LED Status Indicators (for power supply mode)

LED	Description
Green	The power supply functions normally.
Red	The LED will present a constant red light when the abnormal status (OTP, OLP, fan fail) arises.
Red (Flashing)	The LED will flash with the red light when the internal temperature reaches 60° C; under this condition, the unit still operates normally without entering OTP. (In the meantime, an alarm signal will be sent out through the PMBus/CANBus interface.)


※ LED Status Indicators (for charger mode)

LED	Description
Green	Float (stage 3)
Orange	Charging (stage 1 or stage 2)
Red	The LED will present a constant red light when the abnormal status (OTP, OLP, fan fail and charging timeout) arises.
Red (Flashing)	The LED will flash with the red light when the internal temperature reaches 60° C; under this condition, the unit still operates normally without entering OTP. (In the meantime, an alarm signal will be sent out through the PMBus/CANBus interface.)




3. Voltage Drop Compensation

- $3.1\,Remote\,Sense\,(For\,24V/48V\,models\,under\,power\,supply\,mode\,only)$
- The Remote Sense compensates voltage drop on the load wiring up to 0.5V



Sense lines should be twisted in pairs to minimize noise pick-up.

- © The +S signal should be connected to the positive terminal of the load whereas -S signal to the negative terminal.
- 3.2 Local Sense (For 24V/48V models under power supply mode only)
- ** The +S,-S have to be connected to the +V(signal),-V(signal), respectively, as the following diagram, in order to get the correct output voltage if Remote Sense is not used.



4. Output Voltage Programming (or, PV / remote voltage programming / remote adjust / margin programming / dynamic voltage trim)

※ In addition to the adjustment via the built-in potentiometer, the output voltage can be trimmed to 50~125% (24/48V models) or 50~120% (380V model).

In addition to the adjustment via the built-in potentiometer, the output voltage can be trimmed to 50~125% (24/48V models) or 50~120% (380V model).

In addition to the adjustment via the built-in potentiometer, the output voltage can be trimmed to 50~125% (24/48V models) or 50~120% (380V model).

In addition to the adjustment via the built-in potentiometer, the output voltage can be trimmed to 50~125% (24/48V models).


In addition to the adjustment via the built-in potentiometer, the output voltage can be trimmed to 50~125% (24/48V models).

In addition to the adjustment via the built-in potentiometer, the output voltage can be trimmed to 50~125% (24/48V models).


In addition to the adjustment via the built-in potentiometer, the output voltage can be trimmed to 50~125% (24/48V models).

In addition to the adjustment via the built-in potentiometer, the output voltage can be trimmed to 50~125% (24/48V models).


In addition to the adjustment via the built-in potention to t of the nominal voltage by applying EXTERNAL VOLTAGE.



© For Remote Sense / Local Sense, please refer to "Voltage Drop Compensation" section.



- O For power supply mode
- The 100% output voltage is 24/48/334V.




- The rated current should change with the Output Voltage Programming accordingly.
- The 100% output current is 133/67/9.6A.
- © For Remote Sense / Local Sense, please refer to "Voltage Drop Compensation" section.




5. Constant Current Level Programming (or, PC / remote current programming / dynamic current trim)

- ※ The constant current level can be trimmed to 20~100% of the rated current by applying EXTERNAL VOLTAGE.
- 💥 If setting output current to a much lower level, as output status turns to constant current mode, it might cause higher current ripple under such condition.




- © For Remote Sense / Local Sense, please refer to "Voltage Drop Compensation" section.
- Output will shut down after O/P voltage is below < 80% of Vset for 5 sec, re-power on to recover.



- The 100% output current is 133/67/9.6A.
- O Notice the output power do not over rated power (max.)

6. Remote ON-OFF Control

The power supply can be turned ON/OFF individually or along with other units by using the "Remote ON-OFF" function.



Between Remote ON-OFF and +5V-AUX	Power Supply Status
Switch Short	ON
Switch Open	OFF



7. PMBus Communication Interface


NCP-3200 supports PMBus Rev. 1.1 with maximum 100KHz bus speed, allowing information reading, status monitoring, output trimming, etc. For details, please refer to the Function Manual.

8. CANBus Communication Interface

NCP-3200 supports CAN 2.0B with maximum 250KHz bus speed, allowing information reading, status monitoring, output trimming, etc. For details, please refer to the User's Manual.

9. Alarm Signal Output

※ There are 3 alarm signals, DC-OK, AC-OK and T-ALARM, in TTL signal form, on CN1. These signals are isolated from output. The maximum sink current is 10mA.



DC-OK signal	Power Supply Mode Status	Charger Mode Status
"High" > 3.5~5.5V	Vout ≤ 77%±5%	Vout ≦ 66%±5%
"Low" < -0.5~0.5V	Vout ≧ 80%±5%	Vout ≥ 67%±5%

AC-OK signal	Power Supply and Charger Mode Status	
"High" > 3.5~5.5V	Input voltage ≧ 87Vrms	
"Low" < -0.5~0.5V	Input voltage ≦ 75Vrms	


T-ALARM signal	Power Supply and Charger Mode Status		
"High" > 3.5~5.5V	OFF(OTP or Fan Fail)		
"Low" < -0.5~0.5V	ON(Normal Work)		

10. Parallel Operation

- ※ For parallel operation, please refer to the function manual of DHP-1UT-B(HV) rack system.
- Read installation manual before using this device. For NCP-3200-380 high output voltage model, correct rack system DHP-1UT-BHV should be used.
 Fail to do so will cause permanent damage.


19" Rack shelf	DHP-1UT-B	DHP-1UT-B	DHP-1UT-BHV
Power supply or battery charger unit	NCP-3200-24*4	NCP-3200-48*4	NCP-3200-380*4





※ Input / Output Connector Pin No. Assignment(CN1): C27309-10749-Y

(Any question about Mating connector, please contact MEANWELL'S sales representative.)



Mating Housing C27209-10749-Y

Pin No.	Function	Description		
1,2	-V	Negative output terminal.		
3,4	+V	Positive output terminal.		
5	+12V-AUX	Auxiliary voltage output, 10.8~13.2V, referenced to GND-AUX (pin 7). The maximum load current is 0.8A. This output has the built-in "Oring diodes" and is not controlled by the Remote ON/OFF con		
6	+5V-AUX	Auxiliary voltage output, 4.5~5.5V, referance to GND_AUX(pin7). The maximum load current is 0.3A. The output has the built-in "Oring diodes" and is not controlled by the <i>Remote ON/OFF</i> control.		
7	GND-AUX	Auxiliary voltage output GND. The signal return is isolated from the output terminals (+V & -V).		
8	AC-OK	High (3.5 ~ 5.5V): When the input voltage is ≥87Vrms. Low (-0.5 ~ 0.5V): When the input voltage is ≤75Vrms. The maximum sourcing current is 10mA and only for output. (Note.2)		
9	T-ALARM	High (3.5 ~ 5.5V): When the internal temperature exceeds the limit of temperature alarm, or when fan fails. Low (-0.5 ~ 0.5V): When the internal temperature is normal, and when fan normally works. The maximum sourcing current is 10mA and only for output(Note.2)		
10,24	NC	Standard model: Retain for future use		
11	SCL	For PMBus model: Serial Clock used in the PMBus interface. (Note.2)		
11	CANL	For CANBus model: Data line used in CANBus interface. (Note.2)		
12	SDA	For PMBus model: Serial Data used in the PMBus interface. (Note.2)		
12	CANH	For CANBus model: Data line used in CANBus interface. (Note.2)		
13	Remote ON-OFF	The unit can turn the output ON/OFF by electrical signal or dry contact between $Remote\ ON/OFF\ $ and $+5V-AUX$. (Note.2) Short $(4.5\sim5.5V)$: Power ON; Open $(-0.5\sim0.5V)$: Power OFF; The maximum input voltage is 5.5V.		
14	DC-OK	For power supply mode $ \begin{aligned} & \text{High } (3.5 \sim 5.5 V) : \text{When the Vout} \leq & 77\% \pm 5\%. \\ & \text{Low } (-0.5 \sim 0.5 V) : \text{When the Vout} \geq & 80\% \pm 5\%. \\ & \text{The maximum sourcing current is } 10\text{mA and only for output. (Note.2)} \end{aligned} $ For charger mode $ \begin{aligned} & \text{High } (3.5 \sim 5.5 V) : \text{When the Vout} \leq & 66\% \pm 5\%. \\ & \text{Low } (-0.5 \sim 0.5 V) : \text{When the Vout} \leq & 67\% \pm 5\%. \end{aligned} $ The maximum sourcing current is 10mA and only for output. (Note.2) DC OK is associated with battery low protection.		
15,16	DA,DB	Differential digital signal for parallel control. (Note.1)		
17	PC	Connection for constant current level programing. (Note.1)		
18,19,20,21	A2,A3,A4,A5	PMBus / CANBus interface address lines(for Rack system). (Note.1)		
22,23	A0,A1	PMBus / CANBus interface address lines for Rack mountable front end rectifier. (Note.1)		
25	PV	Connection for output voltage programming. (Note.1)		
26	-V (Signal)	Negative output voltage signal. It is for local sense; and certain function reference; it cannot be connected directly to the load.		
27	-S	Negative sensing for remote sense (For 24V/48V models under power supply mode only)		
	NC	Not available for NCP-3200-380		
28	+S	Positive sensing for remote sense. (For 24V/48V models under power supply mode only)		
	NC	Not available for NCP-3200-380		
29	+V (Signal)	Positive output voltage signal.(For 24V/48V models under power supply mode only) It is for local sense; it cannot be connected directly to the load.		
	NC	Not available for NCP-3200-380		
30	FG	AC Ground connection.		
31	AC/N	AC Neutral connection.		
32	AC/L	AC Line connection.		

Note1: Non-isolated signal, referenced to [-V(signal)]. Note2: Isolated signal, referenced to GND-AUX.